



(RT LINK FIBER OPTIC CABLES)

RT-EN-48C Fiber Optic Splice Closure

Specification

1.Application

This product provides suitable for cable whose diameter is within 22mm. It can be used in aerial, duct and direct buried application as well as the all-plastic local cable connection.

2.Structural features



Second fix design makes the cable more stable

Silicon rubber sealing type makes it easy To reopen



- ◆ It complies with the regulations of YD/T814-2004.
- ◆ The shell material is high quality engineering plastics(ABS), which is anti-aging, anti-corrosion and thunder-proof.
- ◆ The product is with the mechanical sealing structure filled with the sealing material. It can be reopened and reused without changing sealing material.
- ◆ The 3 types of cable rings($\phi 12.5$, $\phi 17$, $\phi 20$) are optional according to users' actual needs, effectively enhancing the reliability and practicability of cable port sealing.
- ◆ The overlay structure of splice tray and the insulated grounding device make it more flexible, convenient and safer for optical cable configuration, dilatation and ground connection.
- ◆ The external components and fastening parts are all made of stainless steel. It can be reopened and reused without changing sealing material.

3.The key technical indexes

- Size(mm): 460*180*120mm
- Weight: 2.6kg
- Fiber radius of curvature: ≥ 40 mm
- Splice tray additional losses: ≤ 0.01 dB
- Storage fiber length: ≥ 1.6 m
- Max capacity(single fiber): 144cores
- Working temperature: $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$

- Lateral pressure: $\geq 2000\text{N} / 10\text{cm}$
- Shock resistance: $\geq 20\text{N.m}$

6. Plastic accessory: 1 set

4. Operating points

- ◆ Choose appropriate cable, strip the cable and remove the outer and inner protective covers and make the tube clean, fill inside the cable, keep 1.1~1.6m fiber and 30~50mm steel core.
- ◆ Fix the cable by pressing cable card, fix core columns. If the diameter is less than 10mm, wind the cable fixed place by self-adhesive rubber belt, fixing the cable after the diameter having reached 12mm.
- ◆ Introduce the fiber into the splice tray, put heat shrink tube and hot-melt tube on any pair of the fiber, after the welding, move the heat shrink tube and hot-melt tube, put on stainless or quartz intensive core column, make the fiber splicing place in the middle of the protective tube. Heat the protective tube appropriately, fusing the fiber and protective tube together. Snap the protective optical fiber connector into cable wireway (every splice tray can be applied for cable of 48 cores).
- ◆ Layout the rest of fibers evenly in the splice tray, order and fix the fiber by nylon ribbon. Generally, use the splice tray in down-top way. After the splicing, put and fix the cover on the top side of splice tray.
- ◆ Apply and locate the ground wire according to the requirements of engineering design.
- ◆ Wind the sealing tape around the entry ports in the shell, put sealing line into the sealing groove in the edge of the shell, close the two pieces of shells, tighten stainless steel bolts. The stress of the bolts should be symmetrical until all the bolts are tightened.
- ◆ According to the laying requirements, locate and fix hangings and lay the closure.

5. Packing list:

1. Main body: 1 set
2. Rack: 1 set
3. Splice tray: configuring according to the quantity of cores
4. Splice package: configuring according to the quantity of cores
5. Stainless accessory: 1 set